

<b>Espesores y tolerancias para vidrios planos</b>				
<b>Espesor (mm)</b>		<b>Tolerancia (mm)</b>		
2	simple	1.80	a	2.13
3	medio doble	2.92	a	3.40
4	doble	3.78	a	4.19
5	semi triple	4.57	a	5.05
6	triple	5.56	a	6.20
8		7.42	a	8.43
10		9.02	a	10.31
12		11.91	a	13.49
15		14.25	a	15.45
16		15.50	a	16.66
19		18.26	a	19.84
22		21.44	a	23.01
25		24.61	a	26.19
32		28.58	a	34.93

<b>Dimensiones máx de vidrios primarios</b>		
<b>Espesor (mm)</b>		<b>Dimensiones máx (mm de semiperímetro)</b>
2	simple	1500
3	medio doble	2250
4	doble	3000
5	semi triple	3750
6	triple	4500

<b>Dimensiones máx de vidrios templados</b>			
<b>Espesor (mm)</b>		<b>Dimensiones máx (mm)</b>	
4		1100	x 700
5		1200	x 900
6		1900	x 1400
8		2750	x 1800
10		3160	x 2040
12		3160	x 2100
15		3600	x 2180
19		4500	x 2180

<b>Dimensiones máx de vidrios laminados</b>			
<b>Espesor (mm)</b>		<b>Dimensiones máx (mm)</b>	
4		1000	x 600
5		1200	x 800
6		1600	x 1400
8		3000	x 1800
10		3500	x 1950
12		3500	x 1950
15		3100	x 1950